

## Instructions on installing the off-the-wall wall-mount faucet system (US Utility Patented)

**Step 1:** Align the back splash case to the top, back of the vanity and screw in the machine screws using the allen wrench until tightened.



**Step 2:** The spacer blocks are pre-installed as shown in the picture. Using this default configuration allows you to fit Danze wall mount rough in model D106800BT. If you prefer to use other brands, you might need to manipulate the spacer configurations/ locations/number of spacers and secure the spacer blocks onto the protruded substrate before you can mount the other rough in valves.



**Step 3:** Connect the flex water supply lines to the rough in, let them go through the 2 holes at the bottom of the case as shown. Then insert the rough in valve stems through the 3 holes on the back splash.



Step 4: Screw in wood screws through the back of the mounting plate into the spacers. You are now completed with the off-the-wall wall-mount system (installation time about 10 min.). Follow the instruction for the faucet trim to complete the faucet installation.

