

installation instructions:

RUSTIC BRACKET/CORBEL

SAFETY INSTRUCTIONS

Make sure to use the correct tools recommended.

Wear safety goggles.

Follow fixture, power tools, and paint manufacturers' instructions and users manuals.

Use common sense and follow good construction practices.

TOOL & MATERIAL CHECKLIST

- electric drill
- drill bit for pilot hole
- countersink bit
- lag screws & washers
- putty knife
- wood putty
- sand paper

IMPORTANT INFO

- Brackets can be heavy and/or awkward to hold. We recommend finding help when placing the bracket in place.
- Be sure to mark the placement of the bracket before fastening in place. It is recommended that you fasten the bracket to a post or beam.

INSTALL INSTRUCTIONS:

1. Mark placement of screw holes using a pencil or marker
2. Drill a pilot hole using a the proper sized drill bit for you lag screw.
3. If you wish to countersink the screws, use the countersink bit to drill a hole deep enough to hide the head of the screw.
4. Using the pilot hole fasten the bracket to the installation are making sure that the screws lock into a post or beam.
5. Fill in the screw holes with wood putty and sand to finish

EXAMPLE DIAGRAM:

