



**FLEXSTONE**  
LUXURIOUS BATH SURROUNDS

## Install Instructions Recessed Caddy

For missing items or returns  
do not return to store.

Please call 877-941-3662

(Monday through Friday 8:00 AM – 5:00 PM MST)

PACKAGED DATE

PACKAGED BY

AND

**\*\* Read all instructions before starting. \*\***



## Recessed Shampoo Caddy Instructions



Please inspect packages for damage or missing pieces, and read instructions carefully prior to installation. All FlexStone products come with a protective masking covering the image side of the material. If you have any questions or issues, please call our customer support Monday through Friday 8:00 AM – 5:00 PM MST at 877-941-3662.

Visit [FlexStoneProducts.com](http://FlexStoneProducts.com) for up-to-date manuals, or to register your product warranty.

**RECOMMENDED:** Visit <http://FlexStoneProducts.com/installation> to access a walk-through video and other useful installation information.

1. Recessed Shampoo Caddies are installed between studs in any wall of your surround. Install the FlexStone Bath Kit surround as normal, but mark locations of studs as you go.
2. Cut a square hole through the FlexStone wall panel, the existing tile (if any), and the sheetrock or cement board. Size the hole just larger than the recessed portion of the caddy (approx. 12.25"). Note: **The hole must be smaller than the flange of the caddy!** Dry fit caddy.
3. Peel away protective masking from the caddy, apply construction adhesive to the back side of the entire flange, filling the cavity on the backside of the flange.
4. Press the caddy into the hole until the flange is flat against the FlexStone wall panel. Secure with painters' tape until the adhesive cures. The cured adhesive will hold the caddy in place and also form a secondary water barrier.
5. Apply 100% silicone, as with the rest of the FlexStone Bath Kit surround, to all corners and edges, as well as all internal corners of the caddy. This forms the primary leak barrier.

