

LBS31T-SLV, -WHT - (1) 31.5" x 9" x 9/16" LocBoard® Pegboard Strip, 8 Hooks

Read all instructions completely before installing. Should you have any questions about your installation, please call Customer Service at 440-248-5480

Review Carton Contents:

- 1 Pcs. LocBoard Pegboard 31.5" x 9" x 9/16" (SLV= Silver, WHT=White)
- 8 Pcs. Assortment of LocHook® Pegboard Hooks
- 1 Pk. Wall Mounting Hardware Packet

- Pegboard Strips fasten directly to concrete, solid wood and hollow wall structures without the use of furring strips.
- Pegboard Strips are designed with internal mounting flanges that keep mounting hardware hidden from sight and add to the board's structural integrity and holding power.
- If installing to bare studs you will need to install wood headers before completing installation.

LocBoard Strip™ Installation:

Tools needed for Installation (not supplied with kit)

Level, marker, 7/32" standard or masonry drill bit, 7/64" drill bit for wood studs, #2 Phillips head screw driver, power drill.

For drywall, hollow concrete wall installation: Use (12 each) plastic drywall anchors and #8 Phillips head wood screws (SUPPLIED WITH THIS SYSTEM). If installing to bare studs you will need to install wood headers before completing installation using wood screws only. NOTE: Always install one board at a time.

1. (IMPORTANT!) Select wall location for your LocBoard Strips. When selecting a location for mounting always make sure that mounting locations do not fall in line with, are adjacent to or interfere with any internal or external electrical wiring, wall mounted or built-in electrical appliances, heaters, gas lines, ductwork or plumbing inside of wall, or are located on the opposite side of any wall surface from where you are mounting. If you are unsure, please consult a professional before proceeding with installation.
2. There are three screw holes in on the top and bottom row of back of your LocBoard Strips that are accessible through the square holes on the front (see images on back).
3. Place one LocBoard Strips with against wall surface, while using a level to make sure your board is straight and squared. Mark the centers of all 6 screw holes onto your wall surface.
4. Pre-drill holes for #8 wall anchors marked in Step 3 using 7/32" standard or masonry drill bit depending on wall surface. If you hit a wood stud stop drilling and using a 7/64" drill bit create a pilot hole for the wood screw, Note: avoid over-drilling holes. (Plastic wall anchors should fit snug.)
5. Insert plastic wall anchors in each hole drilled in Step 4 except where you drilled 7/64" pilot hole for wood stud.
6. Align mounting holes in wall surface with screw holes in back flanges. Insert wood screws through the front square opening and into pre-installed plastic wall anchors. Tighten all screws. The head of each screw should not be visible and will be tight against inside surface of each mounting flange.

Hook Installation: Insert the hook back locking tabs into front square openings of tool board. Slide each hook securely into place and install required number of LocScrews (LocScrews are supplied with each pack of LocHooks.)

Each LocHook has the unique capability of being securely mounted vertically and horizontally. Panels must be securely fastened to sound wall structures to support heavy loads.

Warranty information: Triton Products warrants to the original owner that this product is free from defects in material and workmanship for a period of two years from the date of the original purchase. If this product is defective when used as intended under normal household conditions within the specified period, Triton will replace the product, send a replacement part or issue a refund (at our option) when the consumer provides a proof of purchase (either a bill of sale, receipted invoice or other proof that the product is within the warranty period), along with a full description of the defect.

Liability: Triton Products and/or its Reseller's liability are limited to 100% of the purchase price of the product.

