

## Bath and Vent Fan Installation Foil Tape Usage Instructions

### Typical Applications:

- Designed for exhaust vents and fan connections.

### Proper Installation:

The proper installation of Bath and Vent Fan Installation Foil Tape ensures the tape will perform as designed:

- The surface the tape is adhered to should be clean and dry.
- The tape should be unwound, the liner removed, and placed in position on the ductwork.
- Once the tape is in place, proper pressure must be applied for the adhesive to achieve a permanent bond. A squeegee should be used to ensure the pressure is applied across the entire width of the tape.
- Once this has been completed, the tape is considered installed properly.