

EasyFlex™

ALUMINUM LANDSCAPE EDGING

INSTALLATION INSTRUCTIONS

EACH BOX INCLUDES

- (4) 6' sections of aluminum edging (24' total)
- (12) 10" steel spiral anchoring spikes

Required tools:
Spade, Hammer,
Hacksaw
(Edger/trencher - optional)



- 1** Lay out area to be edged with a garden hose or string to define the area.



- 2** Spade a vertical wedge in ground approximately 4" deep and 3" - 4" wide.



- 3** Begin placing edging in trench with the top 1/2" above what will become the compacted finish grade.



- 4** Slide ends of edging strips together to connect pieces. Adjacent section of edging can be connected prior to or after the sections are in place. Overlap: minimum 2"; preferred: 4".



- 5** Cut edging section to the desired length at the end of the bed area using a hacksaw.



- 6** Drive spikes through holes in edging at a 45 degree angle. Start with the beginning piece of edging.



- 7** Stake and backfill edging continuously to ensure straight lines, compacting both sides to ensure the finish grade is approximately 1/2" below top of edging.



HELPFUL TIPS

- **CORNERS:** Bend edging around a 2 x 4 or other hard object to achieve desired angle. 90 degree corners are available and sold separately.

- **GRADE CHANGES:** Cut "V" shaped notch in bottom of edging and bend to accommodate grade.
- **PROTECTIVE EYEWEAR:** During installation it is recommended to wear protective eyewear.