



# SCREEN DOOR HARDWARE INSTALLATION INSTRUCTIONS

## TOOLS NEEDED



Tape Measure



Drill with 3/32" Drill Bit  
and Phillips #2 Bit



*The process for installing Screen Tight hardware is the same for both wood and solid vinyl screen doors.*



FIG A



FIG B

**IMPORTANT**

### Guides on Hinges

Your hinges have built-in guides to ensure proper installation. Mount the hinges based on the frame/door designation (fig. A) and be sure to push the edge guide on the back (fig. B) up against the edge of your door before mounting.



### 1 Position Hinges

Measuring from the top of your door, mark the door frame at 10", 40" and 67". Position each hinge on the center of each mark.



### 2 Mount Hinges

Align the middle of the hinges with the side of the door by pushing the edge guide against the your door. Mark hole locations and drill 3/32" holes 3/16" deep. Attach with included screws and slide screw covers into place.



### 3 Mount Pull Handles

Mount pull handles at desired height. Usually aligned near the center of the door — about 36 inches from the top of the door.



**Watch our hardware installation video at [ScreenTight.com/Hardware](http://ScreenTight.com/Hardware)**

