

## **Instructions:**

1. Mark screw locations at desired positions.
2. Drill pilot holes angled away from joint.
3. Install and tighten screws.