

HOW TO

Install a No-Calk® Shower Drain



Secure shower drain to shower floor. Use silicone sealant for water tight seal.



Tighten locking nut to secure shower drain to shower floor. Place pre-formed shower stall over pipe and cut to correct length.



Place rubber calking gasket over pipe.



Tighten calking nut with wrench provided to secure shower drain to pipe.

HOW TO Replace A Shower Strainer



Remove old strainer by using a flat-head screwdriver to pry loose from shower drain, if a snap-in strainer. Use Phillips-head screwdriver to remove screws if a screw-in strainer.



Insert new strainer by snapping-into shower drain.