

When installing first find and mark the studs on your wall. Use a stud finder for this process. Now lay out your reclaimed wall boards and group them by width. Use a level to make a line for your first row. Begin installing by using a finish nail or staple gun that will reach into the stud. Where no stud is found use a quick drying construction adhesive on the back of the plank. Then shoot a few nails into the sheetrock to help hold plank until glue cures. Continue this process alternating widths each row to achieve desired look. Don't forget to trim out with Vintage Timbers barnwood trim after completion for the most authentic look. Now enjoy!!