

SF 685 Waterproofing Repair Tape Usage Instructions

Typical Applications:

- For indoor or outdoor use to seal Class 1 Flex Duct, sheet metal and duct wrap vapor barriers.
- Also used for sealing leaks and gaps.

Proper Installation:

The proper installation of SF 685 Waterproofing Repair Tape ensures the tape will perform as designed:

- The surface the tape is adhered to should be clean and dry.
- The tape should be unwound, the liner removed and placed in position.
- Once the tape is in place, proper pressure must be applied for the adhesive to achieve a permanent bond. A squeegee should be used to ensure the pressure is applied across the entire width of the tape.
- Once this has been completed, the tape is considered installed properly.