

INSTRUCTION GUIDE

ROOF COLLARS

Oatey

1 Make sure existing rain collar is dry and clean

2 Put a liberal amount of exterior silicone on the top of the existing rain collar and the underside of the new rain collar

3 Push the new rain collar down over the pipe end and slide it down onto the existing rain collar

4 Press firmly to make sure the new rain collar sets on top of the existing rain collar to ensure silicone is completely compressed

