

We suggest you hire an experienced plumber. Our bathtubs have the drain already installed. If the bathtub has an overflow, it will already be connected to the bathtub drain. All the plumber needs to do is attach the bathtub drain to the floor drain. The preferred method of installation is direct to plumbing. Please see the general freestanding bathtubs installation instructions file.

We also include an optional flexible drain hose. If the optional flexible drain hose is needed for installation due to inability to move the floor drain or no underneath access, one end of the flexible drain hose attaches to the bathtub drain and the other end will need to be attached to the floor drain by using a transition piece that you can find at any home improvement store.