

# EVERBILT™



FOR PLASTIC TUBULAR  
Para Tubular Plástico

# FLANGED WASHER Arandela Embridada

1. Measure and cut wall tube **(B)** to length required.
2. Position nut **(A)** on wall tube **(B)**.
3. Insert wall tube **(B)** into waste connector and tighten existing nut.
4. Position nut **(C)** and washer **(D)** on tailpiece (Use reducer washer **(F)** if tailpiece is 1 1/4 in).
5. Slip tailpiece into J-bend **(E)**.
6. Tighten nuts. CHECK for LEAKS.

- 
1. Mide y corta el tubo de pared **(B)** al largo requerido.
  2. Coloca la tuerca **(A)** en el tubo de pared **(B)**.
  3. Inserta el tubo de pared **(B)** en el conector del desagüe y aprieta la tuerca existente.
  4. Coloca la tuerca **(C)** y la arandela **(D)** en el tubo de conexión (Usa una arandela de reducción **(F)** si el tubo de conexión es de 1 1/4 plg).
  5. Desliza el tubo de conexión en el codo en J **(E)**.
  6. Ajusta las tuercas. VERIFICA QUE NO HAYA FILTRACIONES.

Missing Line Art

Missing Line Art

Missing English and Spanish Instructions