



Adjustable CURVED Shower Rod

Installation Manual

Congratulations, you have purchased the **ARISTA®** quality **Adjustable CURVED Shower Rod!** Its patented snap-fit mounting bracket facilitates an easy installation method to all.

Below is step-by-step instructions that will guide you through in the simple installation.



Adjustable 60" – 72" Curved Shower Rod

In the package, there are two (2) pieces of Snap-Fit Mounting Brackets, two (2) parts of the Curved Stainless Steel Shower Rod, four (4) pieces of mounting screws and four (4) pieces of anchors included.

Mounting of Snap-Fit Brackets

- 1) Hold the Snap-Fit Mounting Bracket on to the desired position on each side of the wall at outside rim of the tub.



Be sure the Snap-Fit Mounting Bracket in correct position with the screw holes at **3 & 9** o'clock positions.

Mark the drilling locations on the wall through the screw holes at the Snap-Fit Mounting Bracket.

Note : Check the Snap-Fit Mounting Bracket on each side of the wall at same height from the floor, in order to ensure the shower rod is level after assembly.

- 2) Drill holes as marked on each side of the wall of the tub.
Two (2) holes for each Snap-Fit Bracket on each side of wall.
- 3) Push an anchors into each hole on the wall until it flushes with the wall.

- 4) Mount each Snap-Fit Bracket on each side of the wall, by screwing the mounting screws provided, through the holes of the Snap-Fit Bracket into the anchors inserted on wall.

Be sure the Snap-Fit Brackets are properly installed with the screws securely tightened.

Installation of Shower Rod to the Snap-Fit Brackets

- 1) Put the two (2) parts of rod together to form a complete Curved Shower Rod :
By sliding the end of the smaller diameter rod (with white plastic cap) into the larger diameter rod.

This Curved Shower Rod could fit 60" – 72" (maximum) showers by sliding in or out of these two parts of rod. No cutting is required.

Note : The end of each rod with the snap-pin is for connecting the Snap-Fit Bracket. The snap-pin ends should be on outside when sliding together to form the complete Curved Shower Rod.

- 2) Press down the snap-pin on one end of the Curved Shower Rod and then, snap into the Mounting Bracket on one side of the wall.

Repeat this step to install the other end of the Curved Shower Rod to the Mounting Bracket on the other side of the wall.

You may use a screwdriver or any hardware to help you press down the snap-pin if needed.

Now, the installation is completed. It is now ready to use with your shower curtain.

For Care :

Clean regularly with warm water & soft cloth. Do Not use abrasive materials, cleaners or detergents as they may be harmful to the finish.

Required Tools (Not included) :

- 1) Philips head screwdriver,
- 2) Level,
- 3) Cordless Drill
- 4) Electronic Stud Finder, if available

Reminder :

- 1) According to any particular shape of your tub, you can adjust the installation position of the Curved Shower Rod slightly more inward or outward from the tub as you desire.
- 2) Unless there is a stud, each screw should be secured on to the wall by using the anchor.
- 3) Do not mount on acrylic or fiberglass type of wall

WT International Inc.
4100 Cedar Commercial Drive
Cedar Springs, MI 49319
1-888-635-0007

2017 ARISTA® is a registered trademark of WT International Inc.
Snap-Fit Mounting Bracket for Curved Shower Rod – Patented