

EarthMinded supplemental instructions: Inserting the front fittings:



1. Crimp the threaded seal into a "U" then insert into the hole from the outside of the barrel



2. Press the seal back into a round – the tab should be flat against the barrel



3. The seal is installed in the barrel - ready to install the fitting



4. Square up the spigot or drain and carefully thread into the seal to avoid cross threading.