

INSTRUCTIONS:

Surface must be clean and dry. Use gloves when working with this product. Measure and cut the desired length from the roll. Do not remove the adhesive backing until you are ready to place the tape. Tape will adhere tightly to the surface and itself. Peel the adhesive backing from the length of tape and press down evenly.

INSTRUCCIONES:

La superficie debe estar limpia y seca. Use guantes al trabajar con este producto. Mida y corte la longitud deseada del rollo. No quite el respaldo del adhesivo hasta que esté listo para colocar la cinta. La cinta se pegará con fuerza a la superficie y a sí misma. Quite el respaldo de toda la longitud de la cinta y oprima hacia abajo de manera uniforme.

Measure and cut
Mida y corte

Peel and place
Quite y coloque

Smooth wrinkles
Alise las arrugas

