

Installation Guidelines

for Moisture Barrier Products



Moisture Barriers

Wall-to-Wall Installation Guidelines

To insure proper performance and durability this product should be installed under the following guidelines.

1 Floor Preparation – Be sure to provide a smooth clean surface prior to installation. All cracks, holes and flooring irregularities should be repaired to ensure a smooth, finished appearance: this prevents accelerated wear and telegraphing irregularities from the substrate. Substrate should be structurally sound and free of foreign substances that could compromise the cushion and the quality of installation. If patching is required, the use of patching compound specifically designed for flooring is suggested.

2 Plan the Layout – Install Carpet Cushion in the longest continuous lengths possible, with cushion seams placed at right angles to carpet seams, or offset at least six inches (150 mm) to one side. Trim cushion flush with the inside contour of the tack strip and securely fasten to the substrate using staples or nonflammable pad adhesive around the perimeter of each room. Secure seams with premium grade vinyl-coated cloth cushion tape.

Complete installation of carpet using methods established and described by CRI Carpet Installation Standards or by the instructions specified by the carpet manufacturer.

Failure to comply with the above methods may void the cushion warranty relieving the Manufacturer of any liabilities or claims against product performance or integrity.



Moisture Barriers

Guía de instalación de pared a pared

Para asegurar la durabilidad y el rendimiento adecuado este producto debe ser instalado bajo las siguientes instrucciones:

1 Preparación del piso (suelo) – Asegúrese de proporcionar una superficie lisa y limpia antes de la instalación. Todas las grietas, agujeros y las irregularidades del suelo deben ser reparadas para garantizar un acabado de aspecto liso: esto evita el desgaste acelerado y que sobresalgan las irregularidades del subsuelo. El subsuelo debe estar estructuralmente sano y libre de substancias extrañas que puedan comprometer el amortiguador de alfombra y la calidad de la instalación. Si se requiere el uso de parches, entonces sugerimos el uso de "Compuesto de Parches" que es diseñado específicamente para el suelo.

2 Planifique la distribución – Instale el amortiguador de alfombra en trozos que sean lo más largo posible y que estén en longitudes continuas, cloque las costuras del amortiguador de alfombra perpendicular a las costuras de la alfombra, si esto no es posible, compense la diferencia dejando por lo menos seis pulgadas (150 mm) hacia un lado. Alrededor del perímetro de cada habitación recorte el amortiguador de alfombra al ras con la parte interna del contorno de la tira bordada y fíjelo al subsuelo usando grapas o pegamento de almohadilla no-inflamable. Asegure las costuras con una cinta de tela recubierta de vinilo de grado Premium.

Complete la instalación de la alfombra utilizando los métodos establecidos y descritos por las normas de instalación de alfombra CRI o por las instrucciones proporcionadas por la empresa de alfombra específica de su producto.

Incumplimiento con los métodos mencionados anteriormente podría resultar en la anulación de la garantía del amortiguador de alfombra, y liberaría a la Empresa de Producción de cualquier responsabilidad o reclamos en contra de la integridad y rendimiento del producto.