



## Installation

1. For a new installation, remove 3 in. of outer jacket from the phone wire exposing four color coded wires. Remove ½ in. of insulation from each colored wire lead.
2. Gently pry the cover off of the mount using the notches at the top and bottom of the cover.
3. Pull the phone wires through a hole in the back of the mount.
4. For an existing installation, secure the mount to the wall box with the screws from the existing wall jack. For a new installation, secure the mount to the wall box using screws and hollow wall anchors (not included).
5. Loosen the terminal screws (1) on the jack and attach the existing four color coded wires to their corresponding color wire terminal on the mount. For example, connect green to green, yellow to yellow, red to red, and black to black. Retighten the screws (1) to secure the wire connections together.
6. Replace the cover and snap into place.
7. Plug your modular phone (not included) into the jack and mount it onto the jack by sliding it onto the screws (2).

