

AC-207 Instructions

1. Remove the existing panels, leaving the frame
2. Measure the height of the window air conditioner
3. Cut the foam panel and the plastic channel to the proper height
4. Slide the uncovered edge of the panels into the frame
5. Remove the protective strip from the plastic channel and press it firmly against the side of the window air conditioner
6. For additional insulation, install the panels on top of the existing panels.