

Retro-Ring™ by RACO®

Installation Instructions for 205RAC & 206RAC models

Step 1 - Using a pencil, transfer the shape of this template onto wall in desired location. Keep sides of template at least 1-1/2" from edge of studs. Template is positioned correctly if these instructions can be read.

Step 2 - Saw along the outline using a drywall saw to create an opening in the wall.

Step 3 - Attach a 4" square electrical box to Retro-Ring™ using the two cover mounting screws supplied with the box (Retro-Ring™ can be used without box for low voltage devices - check your local code). Pass the mounting screws through the unthreaded holes in Retro-Ring™, and thread screws into box.

Step 4 - Position Retro-Ring™ into the wall opening and secure by turning the two retention screws clockwise until ring is secure.

Step 5 (for 205RAC) - Complete wiring of device according to manufacturer's instructions, and secure by screwing the two 8-32 screws supplied with device into threaded holes in the Retro-Ring™.

Step 5 (for 206RAC) - Complete wiring of device(s) according to manufacturer's instructions, and secure to Retro-Ring™ using two 6-32 screws supplied with device. Complete by installing suitable cover plate (not included).



ELECTRICAL PRODUCTS

A Division of Hubbell Incorporated (Delaware)

www.hubbell.com

Patent Pending