

## **1**

Position the garden hose holder in the desired spot on the wall. Place a level on the holder to ensure that it is level. Make sure that the hose will reach the faucet and that it is at a comfortable height. Place the holder on the thin upper edge of horizontal siding if your home has aluminum, wood or vinyl siding or on the brick as opposed to the mortar on a brick home.

## **2**

Mark the screw holes on the wall with a pencil and set the holder aside. Drill pilot holes on the marks using a drill and a drill bit slightly smaller than the diameter of the screws you are using to secure the holder. Use 3-inch galvanized screws (not included) for aluminum, wood or vinyl siding. For brick homes, use 2-inch anchors and screws.

## **3**

Insert the anchors (not included) into the holes if you have a brick home and tap them with a hammer to drive them into the holes. Position the holder over the pilot holes, insert screws and tighten them with a screwdriver to secure the holder.