

Installation Guide

Echo Mirror Tile

INSTALLATION GUIDELINES FOR ECHO MIRROR TILES

Echo Mirror tiles are suitable for wall applications in a clean dry area that are free of debris. This tile is not suitable for a wet environment such as in the shower, pool, or around the tub. Please note Echo Mirror tile is not a tempered tile, but can be made as tempered for projects. These tiles are not recommended for areas where there is high heat.

RECOMMENDED SUBSTRATES:

- (Primed) Tile Backer Board
- (Primed) Un-Painted Gypsum Wallboard
- (Primed) Unfinished Wood
- (Primed) Particle Board
- Concrete

PREPARATION OF SUBSTRATE

Make sure the surface on which the tile will be applied is dry, clean, and free of any dust, dirt, greasy film, paint and/or primer. Any porous surfaces (tile backer board, unpainted wall, wood, concrete, etc.) must be sealed with a primer prior to installation.

SETTING MATERIAL

Echo Mirror Tiles are recommended to be installed using a with Mirror Mastic. Do NOI use adhesives such as Liquid Nails, solvent glues, or any type of construction adhesives as they are not recommended for this particular application.

CUTTING METHODS

Mirror tiles can be easily cut using a Score and Snap Tile Cutter. They can also be cut using a diamond blade on a wet saw.

INSTALLATION

Apply a thumbprint size portion of mastic in all four corners as well as the middle of the tile. Adhere firmly onto substrate, allowing a minimum space of 1/16" for grout joints in between the tiles.

GROUTING

Echo Mirrors can be grouted but is not required. If you choose to grout your product, avoid using a sanded grout as it may scratch the surface of the glass.