

### ASSEMBLY INSTRUCTION:

1. CAREFULLY REMOVE ALL PARTS FROM THE BOX
2. PUT THE TUBING (3) ON THE HUB (4)
3. SCREW THE HUB (4) ON THE BASE (5)
4. PLACE THE SHADE (2) ON THE TUBING (3)
5. SCREW THE SHADE (2) WITH FINIAL (1) TIGHTLY.

