



1. Drill the appropriate drill size hole into drywall/wallboard, brick or concrete. (Please refer to the product packaging for the appropriate drill sizes)
2. Insert the TripleGrip[®] into the hole. Tap in flush to the wall.
3. Insert the screw through the object you need to affix and into the TripleGrip[®] up to the point where the head screw touches the wall to allow the TripleGrip[®] to open behind the wall.
4. Continue to screw until there is a strong resistance.