

## INSTALLATION INSTRUCTIONS FOR REPLACEMENT SEALS FOR KERFED DOORS

- Notice which direction the weatherstripping is facing to install the new weatherstripping the same way.
- If the weatherstripping is kerf-installed, a few firm tugs with vise-grip pliers or needle nose pliers will easily remove an entire side of weatherstripping in one piece. If there is no kerf, use adhesive style weatherstripping.
- If you are replacing all three sides, place the side pieces first, then the top piece.
- Use the old weatherstripping you removed to rough measure the new pieces. Cut with sharp scissors or utility knife. Test fit and trim if necessary.
- Slide the plastic fin of each side piece into the top of the kerf. Starting at a that edge, press firmly along the length every couple inches to seat.
- For a tidy job, before installing the top piece, trim wedges of rubber in the corners to match the miters in the old weatherstripping.
- Close your door to test the fit