

Wallbase Installation Instructions

1. Measure the length of the wall where the wallbase will be installed.
2. Cut the wall base with a miter saw, circular saw or hand saw to the necessary length.
3. Place the wallbase against the wall and test the fit.
4. Nail the wallbase into the wall studs with finishing nails.
5. Fill nail holes with coordinating putty.
6. Use quarter round to cover the flooring expansion gap at the wall base.