



Tools Required :



CINCH® STAIR EDGING

INSTALLATION

INSTRUCTIONS:

STEP 1 - CLEAN: Make sure the surface is clean, dust-free, and dry. To enhance the adhesion, we recommend the surface be sealed or primed prior to placing tape on stair step. Not recommended for carpeted stair steps.

STEP 2 - CUT: Measure and cut Cinch Stair Edging to intended length using a hacksaw or power saw.

STEP 3 - PEEL &

ADHERE: Peel away the film backing from Cinch Stair Edging exposing the adhesive. With the Cinch Stair Edge face fitting securely up against stair step vertical riser, place Cinch Stair Edge (and adhesive tape) on the stair step. Apply firm and consistent pressure across the Cinch Stair Edge in order to properly adhere to the surface. Wait 60 minutes before walking on Cinch Stair Edging.

Note: Do not install Cinch Stair Edging below 50° F.