

How To Apply

1. Start with thoroughly clean and dry fabric free of soap residue. Follow the manufacturer;s directions to remove all soiling and residue
2. Apply outdoors or in a well-ventilated area
3. Test for colorfastness in small inconspicuous area
4. Spray until item is evenly wet slightly overlapping sprays
5. if drops form on surface, wet a sponge with Ray Bloc and gently wipe drop. Do not allow large drops to dry
6. Allow treated fabric to dry completely.
7. Test for UV protection by sprinkling water on surface. If water beads, you are protected. If water beading does not appear sufficient, a second application may be necessary.