

## Glass Block Dryer Vent Installation Instructions

To install a glass block dryer vent in a new glass block window or wall, use the dryer vent block in the place of an 8 in. x 8 in. glass block. The dryer vent can be adapted for either Thinline Series(3" thick) or Premiere Series (4" thick) glass block.

For complete instructions on how to install glass block follow Pittsburgh Corning's Mortar Installation Instructions (GB-243) or ProVantage® Installation Instructions (GB-323).



PITTSBURGH CORNING™