

Installation Guide

You will require: A 1½” interior dimension (flexible hose and hose clamp) or (a solid pipe and caulking) – both are for venting depending on your preference
Vent cover (If required)
Drill and appropriate hole saw (If required)
Phillips screwdriver
Pencil
Measuring tape

The toilet may be placed anywhere you require it.

- The hardware kit containing the following items will be found in the solid chamber:
 - 2 Floor Brackets
 - 2 Floor Bracket Bolts
 - 2 Floor Bracket Screws
- Secure the brackets to the toilet with the bolts provided.
- Position the toilet where installation will be located. Mark location on the floor at least 7” or 18cm from the back wall.
- Trace around the brackets onto the floor, on either side of the toilet.
- Remove the brackets from the toilet.
- Line the bracket up with the traced brackets on the floor, so that the bottom of the bracket will be under the toilet. Attach the brackets to the floor with the screws provided.
- Place the toilet between the brackets, and fasten the brackets to the toilet, with the bolts provided.
- Attach the vent hose, or vent pipe to the fan housing and install the vent through an external wall.
- Plug in fan.

CAUTION

- Do not throw cigarette butts, or other burning objects in the toilet.
- This toilet is intended for regular household use only.
- Unplug toilet before cleaning.