



## **600R RECESS WALL CLAMP**

### **INSTALLATION INSTRUCTIONS:**

1. Cut wall opening as per instructions for desired unit.
2. Insert machine screws through recess unit and start screws into clamp with a few turns.
3. With 600R loosely attached to recess unit, angle the clamp through opening in wall.
4. Tighten machine screws securely while holding recess unit in place.