

Single Post Paper Towel Holder installation instructions:

1. Place in the desired location.
2. Making sure item is level, mark the screw hole locations.
3. Drill the 2 marked spots. Insert drywall anchors in the holes *(unless screw will go directly into a stud)*.
4. Fasten the Single Post Paper Towel Holder to the wall, using the mounting screws.

NOTE: Use a 9/32 in. drill bit for drywall anchor installation.
Use a 1/8 in. drill bit for direct stud installation.

If installing into a material other than drywall or into stud,
consult a professional for proper installation.