

CAL FLOR

SOLUTIONS FOR YOUR FLOORS

VaporBlock Moisture Barrier

6 mil Polyethylene Film

150 Sq Ft

Includes Positioning Tape



**Ideal for:
Laminate &
Engineered Flooring**



**Helps protect floor from
harmful vapor emissions**



**Allows floating floors to expand and
contract over most subfloors helping
maintain flooring warranty**

6 mil x 6' (72") x 25'

Item # GA60240M
Made in China

Cal-Flor Accessory Systems
Oroville, CA 95965
www.cal-flor.com
888-277-FLOR (3567)



0 50462 60240 3

VaporBlock

6 mil Polyethylene Film

Rolls out to 150 Sq Ft

6 mil x 6' (72") x 25'

Cal-Flor VaporBlock helps protect floor from harmful vapor emissions.

Using film over rough subfloors when installing pad-attached flooring allows the flooring to smoothly expand and contract, reducing lateral friction.

Installation Instructions:

1. Always follow the flooring manufacturer's installation instructions with respect to preparing and leveling the subfloor.
2. Unroll VaporBlock PE film. Cut film about 2 inches longer than wall to ensure full moisture protection of the flooring.
3. Overlap adjoining seams by 3". Use attached positioning tape to help align.
4. Tape tears, cuts and end seams with packaging tape to ensure full moisture protection.

**Find Seaming Tape TA82340CF
and all your flooring accessory needs at
www.Cal-Flor.com**

