

AF 975 Cold Temperature Aluminum Foil HVAC Tape Usage Instructions

Typical Applications:

- For use in temperatures ranging from -20 F to 260 F when joining and sealing aluminum-backed or fibrous insulation and metal ductwork.
- Can also be used when repairing metal and sheet metal.

Proper Installation:

The proper installation of AF 975 aluminum foil HVAC tape ensures the tape will perform as designed:

- The surface the tape is adhered to should be clean and dry.
- The tape should be unwound, the liner removed and placed in position on the ductwork.
- Once the tape is in place, proper pressure must be applied for the adhesive to achieve a permanent bond. A squeegee should be used to ensure the pressure is applied across the entire width of the tape.
- Once this has been completed, the tape is considered installed properly.