

APPLICATION GUIDELINES:

1 Shot N Gone Bio-Barrier products are the ONLY products guaranteed, with proper application, to inhibit the growth of Mold, Mildew, Fungus and Odors they cause on surfaces treated with this product for weeks and even years in many applications. For use on virtually any interior and exterior surface.

Step 1: 1 Shot N Gone

Bio-Barrier Coatings are not cleaners they are protectants. You must thoroughly clean and or disinfect the affected areas to remove dirt, grease, mold and its resulting staining prior to applying protectant. We recommend the use of **1 Shot N Gone** Bio-Barrier Cleaner/Prep as it is completely compatible with the protectant or any quality cleaner that leaves no bleach or soap residue. We also recommend Wex-Cide 128 as the disinfectant.

OEM use on new material:

Spray a light mist directly on the surfaces where protection is desired. Crystal clear when dry. Will not change finish or color of substrates.

Step 2: General**Application Guidelines**

May be used in cool environments but DO NOT FREEZE

- COVERAGE average is 800 to 1,500 square feet per gallon depending on porosity of substrate.
- May be applied by spray (air, airless, LPHV, garden sprayer, brush, roller, dip, poured, or cloth/sponge wipe.
- No protective clothing required but a dust mask and protective glasses are recommended for whole room sprayed application. A pair of Playtex type rubber gloves are also recommended in addition to safety glasses when applying.
- SKIN CONTACT: Soap and water clean-up if it comes in contact with skin. Only people with hypersensitivities to chemicals may experience slight redness or irritation.
- **WARNING:** IF A SPRAYER IS USED IN APPLICATION OF PRODUCT YOU MUST RUN CLEAN WATER THROUGH THE NOZZLE AND HOSE. FAILURE TO DO SO WILL RESULT IN A CLOGGED

SPRAYING DEVICE.
APPLICATIONS TO FOOD
PREP AREAS, HOSPITALS
AND LIVING AREAS VISIT:
WWW.BAREGROUND.COM
FOR INSTRUCTIONS