



Manufacturers Advanced Composite Materials, Automotive and Apparel
Specialty Fabrics, Bias Binding, Electrical Insulation,
Narrow Fabrics, P.V.C. Film, Construction, Survey & Safety Accessories

MUTUAL INDUSTRIES INC.

707 W. GRANGE STREET, PHILADELPHIA, PA 19120

800 523-0888

215 927-6000

FAX: 215 927-3388

CUSTOMER SERVICE LINE

PRE-POSTED SAFETY FENCE INSTALLATION INSTRUCTIONS

1. Unroll fence at desired location.
2. Lift starting end of fence upright and hammer the first post into the ground. Posts extend 12 inches below the fabric. It is recommended to drive the posts into ground until the fabric is flush with the ground.
3. Lift the second post upright and pull the fabric taut so that there is no sag in the fence and drive that post into the ground till the fabric is flush with the ground.
4. Continue to work down the length of the fence pulling the fabric taut and driving each post in order until all six are in the ground.
5. The fence is 50 feet in length. If a shorter fence is needed, the fence can be cut at any of the posts, which are 10 feet apart. Alternately, the fabric could be shortened by twisting the fabric around the posts before driving them into the ground to achieve the overall desired length.