

PEEL & STICK

Removable, Repositionable, & Easy to Install

NEXTWALL

Use only one lot number.

Copyright © 2017 NEXTWALL
All Rights Reserved
Made in USA

Pattern

Run/Lot



Preparation

The wall surface should be clean, dry, smooth and free from mildew. We recommend not using NEXTWALL products on textured walls; over existing wallpaper, brick, cinderblock, non-stick paint, unpainted drywall or plaster.

Hanging Instructions

1. These wallcoverings are inspected and tested - however, they should be checked for defects before hanging. We will replace defective merchandise but assume no responsibility for labor charges for the application or removal of any wallcoverings. The hanging of more than 3 strips constitutes acceptance of the product. On plains and textures, we recommend reverse hanging the strips.
2. Measure the wall height and pre-cut strips to match wall height, noting to add an extra 1-2 inches for trimming at both the top and bottom. Cut and trim NEXTWALL product with a razor sharp knife, changing the blade often to help maintain a smooth clean cut.
3. Starting on the left side of your wall, measure out from the corner 20.5" (52.07cm) or 27" (68.58cm) depending on the width of the product and mark the wall lightly with a pencil. Use this mark for your level, drawing a straight vertical line. This line is the guide for your first strip so it is important that it is straight.
4. Peel about 12" (30.48cm) of the backing away from the paper. Apply the paper to the top of the wall, allowing that 1-2 extra inches to

overlap the ceiling which will be trimmed off later. Align the right side of the strip with your vertical line and lightly press the edge to the wall along the line. If needed you can reposition to ensure a vertical seam. Working from the top to the bottom, pull the backing away from the paper as you evenly press the paper to the wall. Do not force the paper and be careful not to pull or stretch the product or the pattern will not align. To achieve the best results we recommend having one person guide the paper at the top and along the seam, while the second holds the opposite edge away from the wall until the seams are aligned.

5. Using the plastic smoother, make your way down the strip in a back and forth motion, smoothing the material to the wall and pushing out any air bubbles.
6. Trim off the excess material at the ceiling and baseboard with a ruler and sharp razor.
7. Repeat this process aligning your next strip to the right edge of your previous strip.

Removal

To remove NEXTWALL slowly pull the edge from the top corner directly downward. NEXTWALL can be repositioned and easily removed.

Cleaning

NEXTWALL may be wiped clean with a damp cloth, using excess liquid may damage the product and we do not recommend.