



GRONOMICS® RUSTIC SERIES “TOOL FREE ASSEMBLY”

48” x 48” x 6.5” MODULAR RAISED GARDEN BED - ONE LEVEL Parts Check List and Assembly Instructions

STEP I

A) Unpack all of the parts and organize them in ‘like’ stacks. Please read the instructions in its entirety before beginning assembly.

You should have:

Model #MRGB-1L 48-48

| QUANTITY | PART DESCRIPTION | PART # |
|---|---------------------------------------|--------------|
| 4 | 4” x 4” x 6.5” Corner Post | R8001 |
| Parts for the Sides | | |
| 4 | 45” x 5½” x 1” Side Rail (One w/logo) | R4501,R4501L |
| Packaged & Inspected by: _____ Date _____ | | |

NOTE: If you need assistance with parts or have assembly questions, please contact Customer Service either via email at info@gronomics.com or phone at 763-753-7374.



GRONOMICS® RUSTIC SERIES “TOOL FREE ASSEMBLY”

STEP II

- A) Start with two 4” x 4” x 6.5” corner posts, place the posts upside down.
- B) Slide one 45” x 5½” x 1” side rail between the two posts. (see figure 1) Repeat the same process with the other two 4” x 4” x 6.5” corner posts and another 45” x 5½” x 1” side rail.

(Figure 1)



STEP III

- A) Connect the two corner posts by sliding a 45” x 5½” x 1” side rail into each post. (see figure 2)
- B) Slide the remaining 45” x 5½” x 1” side rail into the posts. Make sure to place the 45” x 5½” x 1” side rail w/logo on the top, with logo facing right side up.

(Figure 2)



STEP IV for MULTIPLE KITS

- A) See box labeling for multiple configuration options. Simply stack or expand in any direction. Posts can be left as is for future expansion or add a decorative cap to complete the look.

(Figure 3)



Note: Ground preparation is optional; we recommend leveling area under frame of bed before placing bed and filling with soil.