

# D301-1

## INSTRUCTIONS:

1. To remove old shower arm and flange place strap wrench around arm and turn counter-clockwise.

Pull old flange off.

2. Apply pipe joint compound or Teflon™ tape to new shower arm threads. Push new flange on and thread into fitting in wall. Turn arm clockwise until straight and tight.

## INSTRUCCIONES:

1. Para sacar el brazo existente de la ducha tomarlo con una llave para tubos y hacerlo girar en sentido antihorario. Sacar la brida existente.

2. Aplicar sellante de rosca o cinta de Teflon™ en los filetes de la rosca del brazo nuevo. Luego colocar la brida nueva y enroscarlo en el tubo de la pared. Gire el brazo en sentido de las manecillas de reloj hasta que esté derecho y ajustado.

