



Curtain Rod Measurement Guide

There is no industry standard in relation to curtain rod measurement. The length of the curtain rod you choose will depend entirely on your preference. The length of the rod should be the same length as the area that you want to cover with your drapes. Ideally you want to ensure that the curtain rod is long enough so the drapes cover the light coming in from the sides of the window as well as from the front of the window itself. We recommend you add an additional 4" from the window casing on each side.

For additional information please review the image below and watch our video tutorial on YouTube

<https://youtu.be/-Np5vacRFKU>

