



Manufacturers Advanced Composite Materials, Automotive and Apparel
Specialty Fabrics, Bias Binding, Electrical Insulation,
Narrow Fabrics, P.V.C. Film, Construction, Survey & Safety Accessories

MUTUAL INDUSTRIES INC.

707 W. GRANGE STREET, PHILADELPHIA, PA 19120

800 523-0888

215 927-6000

FAX: 215 927-3388

CUSTOMER SERVICE LINE

SNO GUARD FENCE INSTALLATION

Suggested Installation Instructions:

1. Place T-posts no more than 10 feet apart. (Note: Metal U-post or rebar are not recommended as supports for fences.)
2. Pull fence taut and secure to the posts with plastic fence ties (zip ties). Loop the ties through the available holes or “teeth” in the post to prevent the fence from sliding down the post. Place zip ties every 12 inches vertically down the fence post.
3. For additional longevity pull the fence taut and secure between the flat side of the T-post and the wood slat. Or weave the slat through the fence mesh, and use it as a tension bar to pull the fence snug. Then secure the slat to the post. Use plastic fence ties (zip ties) to secure the slat and fence to the T-post at the top, middle and bottom of the fence. Loop the tie through the “tooth” at top and bottom of the post to prevent the fence sliding down the post.
4. For the greatest longevity of the fence, it can be suspended from a wire (plastic, metal, rope, etc.). This is in addition to the securing method explained in #3 above. This wire should be woven through the upper openings of the fence and through the holes in the posts. The wire should then be secured at both ends of the fence.
5. To connect fence sections, overlap two ends by at least 6 inches and weave a wood slat through the overlapped strands. Secure the joined area to the T-post.