



How-To-Use

SikaLatex® R

Bonding Agent & Admixture

Materials:

- Safety glasses and waterproof gloves
- Gallon of Sika Latex R
- Mixing container
- Wire brush

Procedure

As a Bonding Agent

1. Remember to always wear waterproof gloves and safety goggles whenever mixing or using cement-based products.
2. Add 1 part cement, 2 parts sand, and a sufficient amount of Sika-Latex R to produce a creamy paint consistency.
3. Brush the mixture with a stiff bristle brush into the entire area to be resurfaced. Make sure the entire surface and all edges are covered.
4. Apply the repair mortar immediately, before the bonding agent dries.

As an Admixture

1. Add SikaLatex R to repair mortar or concrete instead of water, and mix to a desired consistency. Follow the concrete or mortar instructions to correct proportions. Add more SikaLatex R as desired.



Guía de Uso

SikaLatex® R

Puente de Adherencia y Aditivo

Materials:

- Gafas y de seguridad y guantes impermeables
- El galón de SikaLatex R
- Recipiente de mezclado
- Cepillo de alambre

Procedure

Como Puente de Adherencia

1. Recuerde de siempre usar guantes impermeables y gafas de seguridad al mezclar y usar productos con base en cemento.
2. Mezcle 1 parte de cemento, 2 partes de arena y suficiente SikaLatex R hasta obtener una consistencia cremosa fluida.
3. Restregue la mezcla con un cepillo o brocha en el área de reparación. Asegúrese de que toda la superficie y los bordes sean cubiertos.
4. Aplique el mortero de reparación, antes de que el puente de adherencia se seque.

Como Aditivo

1. En vez de agua, añada el SikaLatex R al moretero o al concreto, mezcle a la consistencia deseada. Siga las proporción de mezcla para concreto y mortero. Si desea puede añadir más SikaLatex R.