



## WILTSHIRE FURNITURE FEET INSTALLATION GUIDELINES

Every successful furniture foot installation begins with good planning and action. Be sure to plan for the proper amount of parts required for your project and the correct fastening components. Make sure that all aspects of the furniture or cabinet you are supporting are considered and discussed to insure that your furniture foot installation will be smooth and that your support products will be sufficient.

*Note that this installation document should not be considered a specific recommendation for your particular application. Federal Brace cannot provide installation guidelines to meet the particulars of every application. This document should be considered a help sheet that provides considerations about the general characteristics of a particular type of support and installation*

### Characteristics of the Wiltshire Furniture Foot

Our Wiltshire Furniture Foot is designed to be mounted to the bottom of a cabinet, island or a piece of furniture. The thick stainless steel material is designed to support all types of applications and the weight that might accompany the cabinet or furniture.

### Preparations for the Wiltshire Furniture Foot

The installation of our Wiltshire Furniture Foot will require a hanger bolt or a dowel. This will be determined by what you are

installing the Wiltshire on and how the receiving end is made. If mounting directly into wood with a pilot hole then a hanger bolt is required. If a threaded insert is in place on the furniture then it will receive a dowel to install.

### Considerations when Installing the Wiltshire Furniture Foot

The Wiltshire should be installed on all four corners of cabinets and furniture where applicable. You will want to make sure your furniture or cabinet base is prepped for the furniture foot. This may mean drilling a pilot hole if you are using a hanger bolt or a larger hole if a threaded insert is the desired install method. Insert the hanger bolt (fine thread end) or dowel into the tapped hole on the Wiltshire till you meet the coarse threads on the hanger bolt or half the length of the dowel. If using the hanger bolt, drill a pilot hole into the wood bottom of the cabinet or furniture piece. Insert the hanger bolt and tighten until the foot is flush.

When using the dowel, a larger hole with a threaded insert in place is already installed in your piece, so you will simply insert the dowel into your furniture or cabinet and tighten until flush. If preferred, you can create this application by drilling a hole slightly larger than the threaded insert. Push the insert into the hole. Then insert the dowel and tighten the foot in place. The "teeth" on the insert will grip into the wood to create a tight installation. Adjust feet as needed for level application by tightening or loosening fasteners. This should only be a minute amount.

"Once all the supports are in place, wipe them down to get rid of any handprints or other debris. The final step is to enjoy your work and your new look! We are thankful you chose the Wiltshire Furniture Foot from Federal Brace. We love seeing our customers' applications so please send us images of your installation and our feet supporting your application. Also, know that the highest compliment Federal Brace can be given is a reference from our customers to friends and family. If you have enjoyed your buying experience with Federal Brace please let someone know."



For any questions or comments please to contact us by email at [customer.service@federalbrace.com](mailto:customer.service@federalbrace.com) or by phone at (877) 353-8899. If you are a visual learner, check out our installation videos on our YouTube channel Don't forget to share your projects with your new Federal Brace brackets on Twitter and Instagram, just tag us @FederalBrace. Like us on Facebook, and check out our boards on Pinterest for more home improvement/decor and DIY project ideas.

