









EpoxyÉlite EVO

EPOXYELITE EVO• APPLICATION

1		Empty completely all the contents of the catalyst (B) onto the paste (A).
3		Mix using an electric drill equipped with mixing paddle (Never mix only by hand with a trowel). Scrape the walls of the bucket to eliminate all parts of non-catalysed product.
4		The joints must be dry. Introduce the mortar into the joints using the suitable green rubber float spreading diagonally across the joints. Remove the excess product.
5		The grout must be cleaned while the product is still wet. Sprinkle clean water. Initial cleaning using a moistened white felt scrub pad making circular movements. Ensure no water enters the joints.
6		Now perform a second cleaning with a rigid cellulose sponge.
7		Any stains of the transparent product can be removed after 24 hours or anyway after the gap has hardened. Use LITONET (floors) or LITONET GEL (walls) or use equivalent Tile Doctor Haze Remover. Spread Litonet or Litonet Gel with the white felt scrub pad.
8		Leave on for 15-30 minutes. Scrub the surface with the white felt scrub pad.
9		Rinse with clean water. Dry immediately with a clean cloth and do not wait for the evaporation of the rinse water.



ADVISED TOOLS



LITOKOL®
HI-PERFORMANCE BUILDING PRODUCTS

Made In Italy

the
Tile Doctor

EXCLUSIVE DISTRIBUTOR FOR USA
Tile Doctor
www.TileDoctor.com
877-TileDoc (845-3362)