

RD-2 Roto Digger

Specifications:

30" Long

1 3/4" Diameter

10" Flighting Length

5/16" Shaft

Verdigris Coating

Front Copy:

Roto Digger

Digs holes up to 28" deep and 1 3/4" wide

It digs for you! Just insert into any 3/8" or larger electric or cordless drill

Plant Bulbs, Bedding Plants and Seedlings

Electrical or sprinkler installations under sidewalks

Insecticide applications and termite treatments

Deep water, aerate and fertilize trees and shrubs

Gets the weeds, roots and all

Guaranteed Forever

Back Copy:

Operating Instructions

1. Insert Roto Digger into drill with pointed tip away from drill. Tighten drill chuck securely.
2. Hold the drill firmly with both hands. Place the drill tip of the Roto Digger straight down into ground where you wish to dig. Start drill slowly. Do not push too hard. Medium speed is adequate to operate the Roto Digger. Allow Roto Digger to drill its own hole. Dig down 2" – 3" then slowly pull out, allowing dirt to spin off. Repeat until desired depth is reached. Works best in damp soil. **Caution: If you hit a rock, root or other object, you will have to relocate the hole. Roto Digger is not designed to dig through hard materials.**

PLANTING Consult your local nursery for proper depth and spacing of bulbs and plants. Drill hole to desired depth. Insert the bulb or seedling. Cover with soil.

TREE AERATION To aerate or fertilize trees and large shrubs, drill holes two feet apart around the outside drip line. Insert fertilizer into holes. For improved long term drainage, fill in holes with gravel or pebbles.

ELECTRICAL WIRING To install electrical wiring under sidewalks, dig down with a shovel on each side of walkway. Be sure to dig at least 3" deeper than the thickness of the sidewalk. Begin drilling hole at a slight slant from below the edge of the sidewalk. Dig 2" – 3" at a time and remove dirt until hole is about half way under the sidewalk. Insert broom or rake handle into the hole. From the other side, line up Roto Digger with the handle and repeat the drilling process. The handle should move when the holes meet. Feed the wire through the hole.

IRRIGATION PIPE OR PVC To install pipe under sidewalks, run 6" – 8" trench up to edge of both sides of walkway. Drill a horizontal hole rather than a slant hole. Dig 2" – 3" at a time and remove dirt until hole is about half way under the sidewalk. Repeat from the other side. Insert pipe through the hole.

TERMITE BARRIERS For insecticide applications, drill hole to depth specified by insecticide manufacturer. Follow all manufacturer's directions and cautions specified on the label.

WEEDING For weeding, center the Roto Digger point directly over the center of the weed and drill down until the root is removed.

CAUTION: USE ONLY IN SOIL. Avoid rocks, tree roots and other objects. Roto Digger is not designed to drill through this material. Wear eye protection. Do not grasp spinning Roto Digger. Do not use near underground utilities. Use caution around underground sprinklers.