




UNIDOOR/UNIDOORLUX/UNIDOOR PLUS

SINGLE SHOWER DOOR INSTALLATION INSTRUCTIONS

IMPORTANT

DreamLine® reserves the right to alter, modify or redesign products at any time without prior notice. For the latest up-to-date technical drawings, manuals or any other details please refer to your model's web page on DREAMLINE.COM



Right-hand installation shown


ATTENTION: This model is also available with the half etched glass option. Please see specific installation instructions on page 17 when applicable.

Please read these instructions carefully before installing. If you have any questions regarding installation, please call our technical support specialists Monday through Friday 8:00am – 7:00 pm EST at Phone: [1-866-731-2244](tel:1-866-731-2244), Fax: [1-866-857-3638](tel:1-866-857-3638) or e-mail our technical support group at support@DreamLine.com.


For more information on [DreamLine® Shower Doors](http://DreamLine.com) and [Enclosure](#) please visit DreamLine.com

Job Name: _____ PO# _____ Date: _____


UNIDOOR STYLES




Style A




Style B




Style C




Style D




Style E




Style F




Style G



Style I




Style J




Style L


Additional styles using glass-to-glass hinges:




Style M




Style M1



Style M2



Style M3



Style M4

STYLE A

UNIDOOR Single shower door 23"-30"

Refer to detailed diagram on page 5 for assembly

STYLE B *

UNIDOOR Shower door with 6" small or 12"-30" large stationary panel

STYLE C *

UNIDOOR Shower door with 12"-30" large stationary panel

STYLE D *

UNIDOOR LUX Shower door with 6" small or 14"-30" large stationary panel

STYLE E *

UNIDOOR LUX Shower enclosure with 30" return stationary panel

STYLE F *

UNIDOOR PLUS Shower door with 6"-34" in-line stationary panel secured using u-channel

STYLE G *

UNIDOOR Shower door with 6"-34" in-line half wall panel secured using u-channel

STYLE I *

UNIDOOR PLUS Shower enclosure with 6"-34" in-line stationary panel and 30"-34" return panel secured using u-channel

STYLE J *

UNIDOOR Shower enclosure with 6"-34" in-line half wall panel and 30"-34" return panel secured using u-channel

STYLE L *

UNIDOOR PLUS Shower enclosure with 30" - 34" return stationary panel secured using u-channel

Additional styles: using glass-to-glass hinges:**STYLE M ***

UNIDOOR Shower door 23"~30" with 6" or 24" hinge panel

STYLE M1 *

UNIDOOR Shower door 23"~30" with 6" or 24" hinge panel and full height inline panel secured using u-channel

STYLE M2 *

UNIDOOR Shower door 23"~30" with 6" or 24" hinge panel and inline buttress panel secured using u-channel

STYLE M3 *

UNIDOOR Shower door 23"~30" with 6" or 24" hinge panel and full height inline panel and full height return panel secured using u-channel

STYLE M4 *

UNIDOOR Shower door 23"~30" with 6" or 24" hinge panel, in-line buttress panel and buttress return panel secured using u-channel

STYLE L1 *

UNIDOOR Shower door 23"~30" with 6" or 24" hinge panel and full height return panel secured using u-channel

All sizes shown above are nominal dimensions

*** For the panel installation instructions, please refer to the separate manual included in the panel glass packaging.**


NOTE: The Unidoor series doors and enclosures are reversible for left or right hand installation. This manual will show the right hand installation. For a left hand installation, simply begin on the opposite wall and reverse the orientation of the parts as necessary.

Preparation


1. Prior to installation, examine all boxes and packages for shipping damage and compare piece count with your packing slip. After opening all boxes and packages, read this introduction carefully. Check that all of the needed parts are included in the package by marking all the components on the "Detailed Diagram of Shower Door Components". If the unit has been damaged, has a finishing defect, or has missing parts, please contact our customer support department within **3 business days** of the delivery date. Please note that **DreamLine® will not replace any damaged products or missing parts free of charge after 3 business days or if the product has been installed.** Feel free to contact DreamLine® if you have any questions and please provide a purchase order#, name or other proof of purchase to help us identify your original order.
2. **Please note that you should consult your local building codes with questions on installation compliance standards. Building and plumbing codes may vary by location, and DreamLine® is not responsible for code compliance standards for your project and will not accept any returns.**
3. If this unit is going to be installed in new construction, please install all of the required plumbing and drainage before installing the shower. **Use a competent and licensed (if required by local code) plumber for all plumbing installation.**
4. Please make sure that prior to beginning the installation, the surfaces are leveled and solid and will be able to support the total weight of the unit. Also make sure the walls are at right angles. Irregular installation surface level, radius corners or improper angle of side walls will result in serious problems for your installation. Please, note that some adjustments and drilling might be necessary during the installation process.
5. Please protect all primary surfaces of the product during installation. Never set your glass down directly onto a tile floor. Leave corner protectors in place until necessary to remove them. Always use a piece of wood or cardboard to protect the bottom edge and corners of the glass prior to and during installation.
6. The **single** Unidoor installation does NOT have any adjustment for out-of-plumb conditions. Please verify that your walls are plumb before proceeding with the installation.
7. **Professional installation is recommended** for this heavy glass frameless shower door.

NOTE: DO NOT attach the handle to the door glass until instructed to do so. DO NOT use the handle to lift the glass during installation. This may result in damage to the glass and/or serious injury. Always use an assistant and/or a professional grade glass suction cup when handling heavy glass panels.


Tools Required



**Tape
Measure**



Pencil



**Phillips
Screwdriver**



**Drill bit
(Ø=1/4")**




**5/8"
Wood shim**



Level




**Electric
Drill**



Knife

Detailed Diagram of Shower Door Components



Packing List

Part#	Description	Qty	Part#	Description	Qty
01	Glass door	1pc	06	Side strip (3 sections to cut)	1pc
02	Handle	1pc	07	Bottom anti-water strip	1pc
04	Countersunk screw ST5×70	8pcs	08	L-shaped strip	1pc
05	Hinge with Adjustable angle	2pcs	31	PVC hinge spacer	4pcs

NOTE: Unpack your unit carefully and inspect it. Lay out and identify all parts using the detailed diagram and packing list in this manual as a reference. Before discarding the carton, check for small hardware bags that may have fallen to the bottom of the box. If any parts are damaged or missing, please contact DreamLine® for replacement.

Part #8 "L-shaped strip" used with single door installation only.


NOTE: Retain these installation instructions for future reference.

Single Shower Door Assembly and Installation

NOTE: The following shower door installation instructions should be used as a general guide and prerequisite to the installation of the UNIDOOR, UNIDOORLUX and UNIDOOR PLUS models. Before you begin the installation, please check your finished opening size. Specific size information can be found on our website at DreamLine.com.

ATTENTION:

This door is extremely heavy and the hinges on this door must be attached to the studs or to preinstalled 2 × 6 wood reinforcement behind the wall.



1. Attach the **Hinges (05)** to the **Glass door (01)** using at least one (2mm) vinyl hinge gasket per side.

See Fig. 1 for details.

ATTENTION:

Never set your glass down directly onto a tile or concrete floor.

Always use a piece of wood or cardboard and leave the corner pads on the glass until it becomes necessary to remove them to protect the bottom edge and corners from damage which could lead to breakage.




Fig. 1

ATTENTION:

For model Styles E, I, J, K & L, that have return panels:
Please check model dimensions for proper placement of the Glass door (01) so that it will align correctly with the return panel glass.

2. Place a piece of **5/8"** thick flat wood or a spacer of equal thickness on the threshold or shower base. Place the **Glass door (01)** on the wood or spacer to ensure that the door height finishes at 72". Carefully butt the door with hinged side against the wall, adjust its position and level it vertically.

ATTENTION:

Check the door glass with a level to verify that it is plumb before marking the hinge positions.

See Fig. 2 for details.

TIP:

If installing the door along with panel glass, temporarily press the 72" Anti-Water strip (Door) (19) onto the vertical edge of the Glass door as a reference to be sure that your door height will match the panel glass at 72".




Fig. 2

3. Hold the door in place and mark the drill holes for both **Hinges (05)** on the wall. Set the door aside and drill the holes in the tile using a **Ø 1/4"** drill bit. Only drill through the tile and let the screw bore into the wood.

IMPORTANT:

The included PVC hinge spacers (31) are provided to compensate for minor out-of-plumb wall conditions. Use only as needed as their use could compromise the opening size of your shower. Please see Fig 4 for an installation example.

Place the **Glass door (01)** back onto the 5/8" thick flat wood or spacer and attach both hinges to the wall with only two **Countersunk screws ST5×70 (04)** on the hinge from outside of the shower. Then open the door and install the remaining screws to the inside of each hinge.




Fig. 3

See Fig. 3 and Fig. 4 for details.

TIP: The PVC hinge spacer can also be used as a template to assist with marking the hinge mounting holes.

NOTE: DO NOT attach the handle to the door glass until instructed to do so. DO NOT use the handle to lift the glass during installation. This may result in damage to the glass and/or serious injury. Always use an assistant or a professional grade glass suction cup when handling the door glass.




Fig. 4

ATTENTION:

The back plate of the hinge from inside the shower locates too close to the drilled holes in the wall and might get scratched by the long screws or screwdriver. Be careful not to scratch the hinge surface.

(OPTIONAL)

4. Carefully remove back plates from the **Hinges (05)** and set the **Glass door (01)** aside.

Screw in the rest of the **Countersunk screws ST5 x 70 (04)** into the wall, place the **Glass door** back to its position and reassemble the **Hinges**. Once the door glass is secure, remove the 5/8" thick flat wood or spacer from beneath the **Glass door**.

See Fig. 5 for details.





Fig. 5

Setting the Adjustable Hinges

The Adjustable hinges are pre-set to overclose to 85° and are adjustable up to 90° after the door is installed. Once the door glass is installed, simply loosen the allen set screws and position the door to the desired closed position. While holding the door in the new closed position, retighten the allen screws and your door will now self-center to the chosen closed position.



4a. Make sure the door glass is plumb and the edge of the hinge is installed flush with the glass edge. Center the hinge in the glass notch and tighten the faceplate screws (Figure 5a). Be careful not to scratch the finished surfaces of the hinge during installation.




Figure 5a

4b. The hinges are factory set to 85 degrees.
You can change this angle by using the adjustment screws
on the hinge plate.
(Figure 5b)




Figure 5b

4c. Use the supplied Allen Key to loosen the adjustment screws on the inside hinge plate, adjust the door to the desired angle (90 degrees for example) then retighten the adjustment screws (Figure 5c). Be sure that you create a tight seal with the supplied strike vinyl when the door is in the closed position.




Figure 5c

5. Mount the **Handle (02)** to the **Glass door (01)**.

See Fig. 6 for details.




Fig. 6

6. Measure the bottom of the **Glass door (01)** from end to end to determine the actual width of the **door**. Cut the **Bottom anti-water strip (07)** to the size of your measurement and notch $3/8''$ of the inner side of the **Bottom anti-water strip as shown**.

Press the **Bottom Anti-water strip** onto the bottom edge of the **Glass door**.

NOTICE:

Make sure the **Bottom anti-water strip** is flush to the vertical edge of the **Handle side** of the **Glass door**.

See Fig. 7 for details.




Fig. 7

7. Get three measurements:

- from the top edge of the **Glass door (01)** to the upper body of the top **Hinge (05)** (+) $7/8"$
- from the lower body of the upper **Hinge** to the upper body of the bottom **Hinge** (+) $1-3/4"$
- from the lower body of the bottom **Hinge** to top of the installed **Bottom anti-water strip (07)** (+) $1-7/8"$

Cut the **Side strip (06)** according to the measurements.

Notch the cut strips to be able to slide them into the **Hinges** and around the sweep vinyl to cover the space to the wall.

Press the cut strips onto the vertical edge on the hinge side of the **Glass door**.

See Fig. 8 for details




Fig. 8

ATTENTION:

Prior to the next step, please be sure that the section of the wall where you need to attach the L shaped strip (08) is clean, dry and free from soap, oil and any construction debris.

8. With the door closed place the ***L-shaped strip (08)** on the door edge and mark its location on the wall.

Please note that the corner of the L-shaped strip (08) should face inward.

With the door opened, remove the tape backing from the adhesive strip and firmly press the **L shaped strip (08)** to the wall.

See Fig. 9 and Fig. 10 for details.

***NOTE:**

The above procedure for installing the L-shaped strip (08) is for the Unidoor Style A single shower door installation only. If installing another model with additional panel glass, please refer to the separate glass installation manual located in the glass packaging for model specific instructions. The vinyl seals that apply to the panel glass are packaged with the panel glass.




Fig. 9




Fig. 10

Product Maintenance

BASES and BACKWALLS: To ensure a long life for your acrylic back walls: wipe them off after each use with a soft cloth. To clean the acrylic back walls use non-abrasive sprays or cream based cleaners. Never use abrasive cleansers, metal brushes or scrapers that could scratch or dull the surface.

GLASS: To ensure long lasting life for your glass shower products: wipe them off after each use with a soft cloth. Rinse and wipe off the glass using either a soft cloth or a squeegee to prevent soap buildup and water spots. To prevent scratching the surface: never use abrasive cleaners and cleaning products that contain scouring agents. Never use bristle brushes or abrasive sponges.

HARDWARE: To ensure a long lasting finish: wipe off the metal parts after each use with a soft cloth. Do not use abrasive cleaners or cleaning products containing ammonia, bleach or acid. If accidentally used, rinse the surface as soon as possible to prevent finish peeling or corrosion. After cleaning the shiny finishes, rinse thoroughly and wipe dry with soft cloth. Never use abrasive sponge or cloth, steel wool or wired brushes.

Style “A”:

Half Etched Glass Installation

NOTE: This model is available with the half etched glass option. Hinged Left installation shown. To install for hinged Right, flip the door to the proper handing.

-The textured surface of the glass door should face out.

See Fig. 11 for details.




Fig. 11



TEL: [866-731-2244](tel:866-731-2244)

FAX: [866-857-3638](tel:866-857-3638)

DREAMLINE.COM

For more information on [DreamLine® Shower Doors](#) and [Enclosure](#) please visit DreamLine.com