

How Install a Prefab Chimney Cap



Prefab Chimney Caps are made to fit over a wood or metal housing; that surrounds a factory built double or triple chimney pipe.

First, measure the length and wide of your housing. Then select the right size prefab cap that will fit over your housing.

Second, measure the inner opening of your chimney pipe. The hole in the center of the prefab chimney cap is 7". So, if your chimney pipe opening is 7" or less than this is the right cap to use. If your chimney pipe opening is larger the 7", than you will need to order a custom size prefab cap with the right hole diameter, so your chimney will draft properly.

Third, make sure the chimney pipe is flush with the top of your chimney housing. If it's not flush, than you will need to cut the chimney pipe down or build up the chimney housing; so that the housing is flush with the chimney pipe.

Fourth, slide the prefab chimney cap over the housing. Make sure it is sitting flat on all four sides of the housing. Using #6 x 5/8" wood or sheet metal screws screw the prefab chimney to the housing on all four sides.

Please note: installion screws **DO NOT** come with the prefab cap.