

Do-It-Yourself Installation Instructions...

The outdoor pre-cut five hole practice greens are designed for Do-It-Yourself installation. Our material is tough and bridges subsurface irregularities.



Putting green installation requires physical exertion and the greens weigh up to 250 lbs. If you are not in good physical condition, do not attempt to install our greens. Please check with your physician before attempting to install this product.

Tools Needed: Hand Tamper, String Trimmer, Safety Glasses, 2' x 4', 3 foot level, yard rake with flat metal side, round nose shovel, leaf rake, square nose shovel and hand trowel.

Follow the step-by-step instructions below to prepare the location and install your new putting green. Happy putting!



Hand tamper, string trimmer, safety glasses, 2x4, 3 foot level, yard rake with flat metal side, round nose shovel, leaf rake, square nose shovel and hand trowel



(1) Select a level site or create one. Greens should not be placed in a depression or drain way. (See leveling diagrams A).



(2) Roll out green and check grade. Grade should not exceed a 2" rise over a 10' run



(3) Outline edge of green with weed eater, or edger (**always wear eye protection**).



(4) Roll up green



5) Weed eat grass inside the outline down to the dirt or roots (**always wear eye protection**).



6) Rake or blow cuttings from outlined area, and cut ridges or roots if necessary. Fill any indentations



7) Add up to 2 lbs. of base for every square foot of green. #8 crusher rock mixed evenly with sand (1 to 1) is recommended for base



8) Create a gentle crown in the center for drainage with a leveling rake or 2x4 and rake the area smooth. No indentations should be present.



9) Compact the base with a hand tamper. A base of #8 crusher rock mixed with paver sand is used because it is resilient and holds it's shape better than pure sand.



10) Check the base for levels and smoothness



13) OPTIONAL: Additional paver sand can be added for smoothness or to create gentle contours in the green. Smooth with edge of level to final desired contour.



(12) Roll out green and check smoothness and contours



(13) Dig in cups with hand trowel or 4 1/4" hole cutter. OPTIONAL: If drainage may be an issue, dig 2-4 inches deeper than the length of the cup and add gravel. Top of the cup should be 1/8" below surface of the green.



(14) If soil is too hard to dig in cups with a hand hand trowel (roots or rocks), mark hole and roll up green at hole. Then, chop up area by hole with a pick or round nosed shovel. Compact area flat and dig in hole.



(15) After the cup is set in the ground, roll up green at hole and compact soil around the cup with the level.



(16) Roll out green and inspect contours and level cups. Cups can be leveled by stepping gently on their edges.



(17) Clean and add markers or flags (optional). Surface can be raked (leaf or carpet rake), blown, vacuumed with a beater bar or hosed off or gently pressure washed.



(18) To change the contours of the green over time, add a bag or two of paver sand to keep the green challenging and fun for years to come.

LEVELING A SLOPED AREA FOR PUTTING GREEN INSTALLATION

