

# Standard Vinyl Hose Manual

## Installation

- Note: Vinyl hose not approved for dryer installations, check your local building codes before installing.
- Make sure there is enough clearance in order to install the hose without kinking. Bend clearance is the diameter of the hose x 2; i.e. A 3” hose has a 6” bend clearance requirement, a 4” hose has an 8” bend clearance requirement. Note: use a close elbow if needed to make a sharp turn (sold separately).
- Secure with hose clamps on each end (sold separately).

Applied Applications International LLC  
500 Colorado Street Kelso, WA 98626  
Phone 1.866.794-7900 / Fax 1.360-577-0876  
Office Hours: Monday-Friday 7:00 AM - 4:00 PM Pacific Time Zone  
[www.speediboot.com](http://www.speediboot.com)

